


integral™ LED

INSTALLATION INSTRUCTIONS
INSTRUCTIONS D'INSTALLATION
INSTALLATIE INSTRUCTIES
INSTRUCCIONES DE INSTALACIÓN
INSTALLATIONSANLEITUNG
INSTRUKCJE INSTALACJI
INSTRUÇÕES DE INSTALAÇÃO

True Solar - Solar LED Wall Light



IS 1001




ILSWL006


1 Installation / Installation / Installatie / Instalación / Installation / Instalacja / Instalação

ILSWL006


1.1



1.2



1.3





2 Function / Fonction / Functie / Función / Funktion / Funkcja / Função



ILSWL006



Before first use




AUTO ON




3 Replaceable battery / Batterie remplaçable / Vervangbare batterij / Batería reemplazable / Austauschbarer Akku / Wymienna bateria / Bateria substituível


3.1




3.2



3.3




3.4




3.7V 18650
2200mAh Li-Ion

3.5



3.6



Warranty/ Technical
& contact information
are all available at
www.integral-led.com



Integral LED is a division of Integral Memory plc:
Unit 6, Iron Bridge Close, Iron Bridge Business Park,
London, NW10 0UF, UK
Integral Europe BV, 2801 DG, NL

IISWLB006_V1