







Integral LED is a division of Integral Memory plc London NW10 0UF

# Colour Temperature Remote Control and Receiver Integral Order Code: ILRC012

# 

THE RECEIVER MUST ONLY BE CONNECTED TO A SUITABLE 12V/24V LED DRIVER.

#### IMPORTANT NOTICE

- · This product should be installed according to the instructions in this guide and by a qualified electrical installer.
- All electrical work must be completed in accordance with the latest IET wiring regulations (formally IEE) for the UK or in accordance with all applicable
  regulations and laws in the country in which it is being installed.
- Switch OFF power at the mains before installing the product.
- Always disconnect or switch off the power supply before making any adjustment to the wiring.
- Observe the operating temperature of the product: -30°C to +55°C

#### 1. Introduction

#### INTRODUCTION

The LTECH Colour Temperature Changing Remote Control and Receiver is designed to work with the Integral LED Colour Temperature Changing Strip (ILSTCTCA075E). You will be able to change the colour of the strip from warm white to daylight to change the mood and look of your space instantly. You can also dim the strip to your ideal level. The strip can also switch from daylight to warm white on continuous basis to add excitement.

### 2. Parameter

#### Receiver:

- · Compatible Remote: M2
- · Power Input: DC12V~DC24V
- · Max Current Load: Max 3Ax3CH
- Max Output Power: 108W(12V)/216W(24V)
- Working Temp.: -30°C~55°C
- Dimensions: L135×W30×H20(mm)
- Weight (N.W.): 47g

Total Weight (G.W.): 140g

#### Remote:

- Working Voltage: 3V (battery CR2032)
- · Working Frequency: 433.92MHz
- · Remote Distance: 30m
- Working Temp.: -20°C~55°C
- · Remote Dimensions: L104×W58×H9(mm)
- Remote Holder Dimensions: L108×W63×H14(mm)
- Weight(N.W.): 42g


# 3. Operating Instruction for Receiver

The Remote control has been matched to the receiver before leaving the factory, if deleted accidentally you can restore the ID as follows.

**Learning ID:** Short press the ID learning button on the receiver until the indicator light is on, then press any key on the remote control, the indicator light flashes several times. The ID is now activated.


Cancel ID: Press ID learning button on the receiver for 5 seconds.


One receiver can be matched to up to 10 remote controls.



## 4. Wiring Diagram

Colour Temperature changing and Dimming






Receiver to strip	
mark on Receiver	mark on Strip
V+	V+
С	W
W	ww

Please make sure you connect the strip to receiver correctly, indicated as following table.

# 5. Operating Instruction for Remote Control

**Sleep mode:** when the touch remote unattended operation over 30s, it can automatically enter standby mode to extend battery life.

Press any of these four keys to continue.



# 6. Product size 135mm 9mm 128mm 128mm Receiver RF remote Remote holder